


should be placed at the critical root zone. A tree's critical root zone can be practically defined as the extent of the dripline despite the fact that a tree's roots often extend two to three times beyond the dripline.



C Copyright 2022

QLOV


1628 N 27th


AREA CALCULATIONS

Heated Area	
1st Floor Livable	1022 SF
2nd Floor Livable	930 SF
	1952 SF
Unheated Area	
Deck	155 SF
Front Porch	116 SF
	271 SF
Total	2223 SF












C Copyright 2021



NOTE:


1. ALL DIMENSIONS ARE FROM OUTSIDE EDGE OF EXTERIOR WALL SHEATHING OR FACE OF STUD, U.N.O.

2. ALL DOOR & WINDOW HEADERS IN EXTERIOR WALLS TO BE (2) 2X8 U.N.O.

3. ALL INTERIOR DOOR HEADERS TO BE (2) 2X4, U.N.O.


4. PROVIDE PRESSURE TREATED LUMBER @ HOUSE BAND WHERE ALL

DECK, PORCH & APPURTENANCES ARE CONNECTED.





C Copyright 2021



NOTE:


1. ALL DIMENSIONS ARE FROM OUTSIDE EDGE OF EXTERIOR WALL SHEATHING OR FACE OF STUD, U.N.O.

2. ALL DOOR & WINDOW HEADERS IN EXTERIOR WALLS TO BE (2) 2X8 U.N.O.

3. ALL INTERIOR DOOR HEADERS TO BE (2) 2X4, U.N.O.


4. PROVIDE PRESSURE TREATED LUMBER @ HOUSE BAND WHERE ALL


DECK, PORCH & APPURTENANCES ARE CONNECTED.







C Copyright 2021




















C Copyright 2021











CHECKED BY: